



E345286

Safe, Green, Energy Efficient

RoHS



Certified LED

Get Green With CERTIFIED!

UL Clasified LED Tube Lamp Variable Voltage **DOUBLE END POWER**

TURN OFF POWER TO THE FIXTURE.

Open the unit and access the ballast chamber.

Disconnect the power to the input side of the fluorescent ballast.

NOTE: THESE CERTIFIED LED LAMPS ARE TO BE POWERED BY LINE VOLTAGE ACROSS THE LENGTH OF THE LAMP. SOCKETS AT BOTH ENDS OF THE LAMP NEED TO BE WIRED AS IN THE DIAGRAM BELOW. THE LAMP LABELS CARRY A “DE” DESIGNATION.

Each socket must have one wire attached. Attach the black power lead to one socket and the white power lead to the socket at the other end. This places line voltage across the lamp.

If more than one lamp is to be used in the fixture, wire each of the sockets in the manner described above. Physical removal of the now unpowered and unused ballast is optional.


Replace the ballast cover.

Install the CERTIFIED LED lamps in the rewired sockets. **DO NOT REMOVE THE PLASTIC PIN COVERS! ALLOW THEM TO BE PUSHED OFF BY THE SOCKET AS THE LAMP IS INSERTED! TOUCHING OF LAMP PINS DURING INSTALLATION CAN BE FATAL IF THE FIXTURE IS POWERED!**

It does not matter which end of the lamp is put in which socket. The lamps are reversible end for end. Close the luminaire. Power up the fixture. The lamps will light instantly.

NOTE: IF THE LED TUBE IS FLASHING, THE TUBE IS SIGNALING THAT THE WIRING IS NOT CORRECT. START OVER AND MAKE SURE ALL OF THE STEPS WERE PROPERLY FOLLOWED.

Wiring diagram: Disconnect ballast and power leads on the fixture. Rewire as shown. Tube will not operate properly unless the power is wired correctly.



Double End Power LED Tube

